

OFS AccuRibbon® Matrix Removal Recommendation

Contents	Section
Materials Required OFS Recommended method for removing ribbon matrix material	1 2

1. Materials Required

This document provides the recommended method for removing ribbon matrix material for separating the ribbon into individual fibers.

1.1 Isopropyl Alcohol.



1.2 Scotch Brite 9000 Professional Pad (Blue).

2. Recommended method for removing OFS Ribbon Matrix

2.1 Separate the individual fibers form the ribbon matrix.





2.2 Apply the alcohol onto the separated fibers.



2.3 Make sure the lint-free wipe has alcohol applied and remains wet.



2.4 Allow the fibers to soak in the alcohol for at least five minutes. The matrix material will begin to loosen.





A Furukawa Company

2.5 Wrap the lint-free wipe around the separated fibers and with pressure applied, pull the wipe down the length of fibers.



2.6 The loosened matrix material will release onto the lint-free wipe.



2.7 Repeat the process until all remaining material has been removed from the individual fibers. Two or three passes should remove the matrix from the fibers.



For additional information please contact your sales representative. You can also visit our website at www.ofsoptics.com or call 1-888-FIBER-HELP (1-888-342-3743) from inside the USA or 1-770-798-5555 from outside the USA.

AccuRibbon is a registered trade mark of OFS LLC.



OFS reserves the right to make changes to the document at any time without notice. This document is for informational purposes only and is not intended to modify or supplement any OFS warranties or specifications relating to any of its products or services. OFS makes no warranty or representation with respect to the non-OFS products or non-OFS companies mentioned in this document.

Copyright © 2017 OFS FITEL, LLC. All rights reserved, printed in USA.