


CS201 Cable Sheath Stripper



CS201 Cable Sheath Stripper


Features and Benefits

- Accurately removes the sheath of a cable without damaging the fiber
- Can be used for making circular and lateral cuts in the cable
- Blade is designed for safety
- Small and lightweight design


Overview

The need for fast Mid-Span Access to the fiber cable core is very important for the rapid growing FTTx market. The CS201 is a tool which can perform mid span sheath stripping reliably, easily, and safely.

Circular cut in cable



Lateral cut along the cable



Specifications

Applicable cable diameter	Ø10 ~ 32 mm
Applicable cable jacket type	Polyethylene Jacket, Laminated Aluminum Polyethylene Jacket (Jacket Thickness : Less than 4 mm)
Weight	Approx. 200 g
Dimensions	Approx. 90W×38D×52H mm
Change blade (Option)	Specify as CS202

For additional information please contact your sales representative.

You can also visit our website at www.ofsoptics.com or call 1-888-fiberhelp (1-888-342-3743) USA or 1-770-798-5555 outside the USA.

**Fusion Splicer Customer Service,
Training and Service Center**

Toll Free: 866-452-9516
Phone: 678-783-1090
Fax: 678-783-1093
Email: splicers@ofsoptics.com

OFS Corporate Headquarters

2000 Northeast Expressway
Norcross, Georgia 30071, USA
Toll Free: 888-Fiber-Help
Intl. Phone: 770-798-5555



Copyright © 2017 OFS Fitel, LLC.
All rights reserved, printed in USA.

OFS Marketing Communications
Doc ID: FITEL-CS201 Date: 11/17

FITEL is a registered trademark of Furukawa
Denki Kogyo Kabushiki Kaisha
DBA Furukawa Electric Co., Ltd.

Furukawa reserves the right to make changes to the prices and product(s) described in this document at any time without notice. This document is for informational purposes only and is not intended to modify or supplement any Furukawa warranties or specifications relating to any of its products or services.



Sheath Removal Instructions:

STEP 1: Use PVC tape to mark the section of Jacket to be removed




STEP 3: Cut the cable laterally between the marked position



STEP 5: Strip the sheath off



STEP 2: Attach the CS201 to the cable



STEP 4: Cut around the cable at the both ends (Circular)



STEP 6: Pull the fiber out

